



ATLAS ANCHOR SYSTEMS

British Columbia Alberta Ontario Washington www.atlas-anchor.com

AS Series anchors mostly need to be embedded in the concrete by pour-in-place, thru-bolt, or adhesive. It can be used on the roof (based on the concrete pier), on the wall, or sit in the flush deck patio box.

Models	Features	Detail	Product Photo
ASP-8100-1R(D)	Pour-in-Place New Construction		
Installation: L-bolt embedded in the concrete, hooked behind rebar. Concrete pier height to the requirements of the Roofing Association and structural engineer.			
ASP-8100-1W	Pour-in-Place New Construction On wall		
Installation: L-bolt embedded in the concrete, hooked behind rebar. Spacers required for non-structural build-up on mounting surface.			
AST-8100-1	Thru-Bolt Retrofit		
Installation: Installation into existing concrete, wood, or steel structure, with back plate on opposite surface. Spacers available for non-structural build-up on mounting surface.			
ASP-8100-1F(D)	Pour-in-Place New Construction On Deck		
Installation: L-bolt embedded in the concrete, hooked behind rebar. Minimum terrace build up is 125 mm (5"). Waterproof membrane must be on top of the concrete slab.			
ASA-7100-4	Adhesive Retrofit		
Installation: Single surface, allows install where access to opposite surface is not available.			

"OUR PRODUCT IS STAINLESS ... JUST LIKE OUR REPUTATION"